

## Hotas Commands - Throttle

Throttle	Action		Selected Sensor Of Interest							
			TAD	TGP	HUD	A-A	MAV	HMCS	HMCS B/S	MSG
Mic Switch	Fwd		Transmit Front Radio (Rotary = VHF)							
	Aft		Transmit Aft Radio (Rotary = Anything)							
	Up		No Transmit (Rotary = Anything)							
	Down		UHF							
Speed Brake	Fwd		Retract Speedbrakes							
	Aft		Extend Speedbrakes							
	Centre		Hold Speedbrakes Position							
Boat Switch	Fwd		TGP FLIR Black Hot				Mav Dark/Cold Light Hot	TGP FLIR Black Hot		
	Aft		TGP FLIR White Hot				Mav Light/Hot Dark/Cold	TGP FLIR White Hot		
	Centre		TGP CCD				Boresight Forced Correlation Auto	TGP CCD		
China Hat	FWD	Short	FOV Toggle	FOV Change LSS FOV Change	Mav Video/Mav SOI	Uncage / Consent to Self Track	FOV Change	TGP FOV Change - LSS FOV Change		
		Long	Slave All to SPI							
	Aft	Short	Reset Cursor	LSS Toggle	Reset/Cage TDC to TVV	Recage / Manual Sequence	Recage / Manual Sequence	Reset/Cage HDC to Crosshair		
		Long	Slave TGP to SPI							
Pinky Switch	Fwd		Position Lights to Dim Steady / Strobes Off							
	Aft		Exterior Lights per Lighting Panel							
	Centre		Black Out all Exterior lights							
Left Throttle Button	D'press	Short	LAAP							
		Long	Image Capture							
Slew/ Track	Slew		Slew TAD Cursor	Slew TGP	Slew TDC	Slew Aim-9	Slew Mav	Slew HDC	Slew Boresight	Slew Cursor
	Z Axis									
Coolie Switch	Up	Short	HUD as SOI		HMCS as SOI		HUD as SOI			
		Long	Message Quick Look							
	Down	Short	Swap Left MFCD and Right MFCD							
		Long	Display DSMS Weapon Status Page & Selected Profile							
	Left	Short	Cycle Left MFCD Page							
		Long	Left MFCD as SOI							
	Right	Short	Cycle Left MFCD Page							
		Long	Right MFCD as SOI							